
### DC12V Highbay installtion Sensor Antenna HD06VCRH









Remote control

10-15M Highbay













#### Technical data

Operating voltage	10-15V DC
Operating current	30mA±5%
Output	DIM 1-10V
Standby power	<0.5W
Detection area	25%/50%/75%/100%
Hold-time	5s/30s/1min/3min/5min/10min/20min/30min
Daylight threshold	2Lux/10Lux/50Lux/Disable
Stand-by period	0s/10s/30s/1min/5min/10min/30min/+∞
Stand-by dimming level	10%/20%/30%/50%
Microwave power	<0.3mW
Microwave frequency	5.8GHz±75MHz
Microwave power	<0.3mW
Detection angle	30-150°
Control line	Ret 12V; Black GND; White -; Yellow +
Mounting height	Max.15m(ceiling mounted)
Detection range	Max.12x15m(ceiling mounted) Max.20m(wall mounted)
Operating termperature	-20°C~+60°C
IP rating	IP65


Note: Motion sensor setting and dimming setting please refer to remote control HD02R. HD06VCRH Standard Version Cable Length 60mm(Can be customized).





#### 03 Detection coverage

# Ceiling Mounted 15m



#### Application Function Demo - Dimmable control/Corridor function



With sufficient daylight, even when motion detected, light remains OFF.



With insufficient daylight, when motion detected, light ON.



After last detection, the light will be dimmed down to the stand-by dimming level (10%,20%,30% or 50%) after holdtime.



After the stand-by period, light OFF.



#### MLLG-LED-HBC 100, 120, 150 and 200

#### **Motion Documentation Supplement**



#### Wiring the motion sensor to the high bay dimming wires

Connect the bracket to the fixtures with the screws included. The motion sensor mounts on the bracket and connect the wires as followed:

Sensor	High Bay Dimming Wires	
Red wire	Black/White wire	
Black Wire and White Wire	Grey wire	
Yellow Wire	Purple Wire	

Plug in High Bay – if motion sensor is hooked up properly, you should see it go bright, and then dim

#### Using the Remote Control to configure the Motion Sensor

Add 2 AAA batteries to the remote control

Turn on remote control – click On/Off

Click Auto Mode

Click SC1, SC2, SC3 or SC4. Refer to remote control documentation. This is a good start to setting up the high bay to do what you want. You can alter each of the settings individually if you are looking for other results. We recommend SC2 as a good start. Here is what SC2 does:

- 1. Detection Area is 100%
- 2. Hold Time is 5 min
- 3. Daylight threshold is about 1 fc
- 4. Stand By Period is 10 min
- 5. Stand By Dimming Level is 10%



#### Here is a brief description of what the remote-control setting means.

**Detection Area**: 100% is widest area of detection, 25% is narrowest. If you're motion sensor is picking up motion it shouldn't, consider a narrower pattern.

Hold Time: the amount of time the light stays bright until the last motion is detected.

**Stand By Dimming Level** - if no motion, this is how much the light dims to. Please note, our lights are 1-10V dimmable drivers, which means the dimmest it will get to is 10%. The only way to turn off the lights is by using the light switch on the wall.

**Stand By Dimming Period** – theoretically, this could turn off the lights. Because our lights are 1-10V, the light will not dim any further than 10%. So if you have set the Stand By Dim Level to 10%, you should not expect it to see the light dim any further. If you set the Stand By Dim Levels to 50%, then the light will initially dim to 50%, then after this dimming period, dim further to 10%.

**Daylight threshold** – we recommend you disable this by clicking the disable button. This works in conjunction with daylight levels with sun light entering the room. If you feel comfortable setting it, just be aware the results might not be as predicted and it might seem the motion sensor is not working. However, most customers disable this feature.

We recommend you configure the lights on the ground before you install them. Once its set up, unplug the lights, install them on the ceiling, and power the lights back on. The sensor will remember all the settings. There is no need to reset or restore the settings if you turn the power on and off

Note: The Motion sensor safety function only allows the unit to dim down to 10% and it never shuts off.

## Standard remote control HD02R

#### **ON/OFF**

Press the "ON/OFF" button, the light keeps permanently on or off.\* Press "Auto Mode", "RESET" or "Scene mode" buttons to quit from this mode.



#### **Detection area**

Press the button "detection range" to set detection range as 100% / 75% / 50% / 10%.



#### **Hold-time**

Press the button "hold-time" to set hold-time as 5s / 30s / 1min / 3min / 5min / 10min /20min/ 30min.



#### Stand-by dimming level

Press the button "stand-by dimming level" to set the stand-by dimming level as 10% / 20% / 30%/ 50%.



#### Stand-by period

Press the button "stand-by period" to set stand-by period as  $0 \text{ s} / 10 \text{ s} / 30 \text{ s} / 1 \text{min} / 5 \text{min} / 10 \text{min} / 30 \text{min} / +\infty$ .


Note: "0s" means no standby period; " $+\infty$ " means unlimited standby period.



#### Daylight threshold

Press the button "daylight sensor" to set daylight threshold as 2Lux / 10Lux / 30Lux / 50Lux/ 80Lux/ 120Lux/ disable.

Note: Disable means light will be turned on once sensor detects movement, regardless of the ambient live



#### **Auto Mode**

Press "Auto Mode" button, the sensor starts to work and all settings remain the same before the light gets switched on/off.

#### Reset

Press "RESET" button, products with DIP switch will be controlled by DIP switches; otherwise all the setting will be just initial, that is 100% detection range,hold time 5S, no stand-by time and daylight threshold disabled.

#### Scene Mode

Scene mode	Detection area	Hold-time	Daylight threshold	Stand-by period	Stand-by dimming level
SC1	100%	30s	2Lux	1min	10%
SC2	100%	5min	10Lux	10min	10%
SC3	100%	10min	50Lux	30min	10%
SC4	100%	30min	Disable	+∞	10%

The button "Test (2s)" is for testing purpose after commissioning. Pressing this button, the sensor goes to test mode (hold time is only 2s) automatically, stand-by period and daylight sensor are disabled.

This mode can be ended by pressing "reset", "Auto mode", "scene mode" or "hold time". The sensor setting is changed accordingly.

#### Attention

- 1. When using ON/OFF button, the rest setting bottons don't work.
- 2. Press "Auto Mode", "scene mode" or "Reset" buttons before setting functions Detection Range, Hold time, Daylight sensor, Standby period and Standby dimming level.
- 3.Press "Scence Mode" and choose one from the existing four scenes.
- 4. When using the remote control, light flickers to show instruction received.
- 5. Every change will be automatically saved.

#### Sensor installation method

The distance between the inductor and the sensor is 4m wide;Recommended installation of sensor suction ceiling height 3-6m;Wall mounting height suggested 1-1.8m;

The remote controls the most remote distance 15 meters (in different places remote control distance will have the deviation)

Weight (including battery): 56.5g

